

INSTRUKCJA UŻYTKOWNIKA

PRZED ROZPOCZĘCIEM MONTAŻU DOKŁADNIE PRZECZYTAJ INSTRUKCJĘ.


1. WAŻNE INFORMACJE DOTYCZĄCE BEZPIECZEŃSTWA

- Produkt nie jest zabawką. Należy trzymać go z dala od dzieci.
- Unikać zabrudzeń i nadmiernego ciepła podczas instalacji i użytkowania.
- Wyłącznie do użytku w pomieszczeniach.
- **Produkt klasy III** - przeznaczony do zasilania ze źródła SELV*
*(Oddzielne lub bezpieczne źródło zasilania o bardzo niskim napięciu.).
- Nie wolno modyfikować ani przeprojektowywać produktu.
- Do produktu nie należy dołączać elementów dekoracyjnych.
- Nie należy wpatrywać się w działające źródło światła.



- Odłącz złącze USB, jeśli wiesz, że produkt nie będzie używany przez dłuższy czas.
- Zewnętrzny elastyczny kabel lub przewód tego produktu nie może zostać wymieniony; jeśli przewód jest uszkodzony, oprawa musi zostać zniszczona.
- Źródło światła tego produktu nie jest wymienne, kiedy źródło światła osiągnie koniec okresu eksploatacji, należy wymienić cały produkt.
- Nie używaj produktu, gdy znajduje się on w opakowaniu.
- Jeśli produkt jest uszkodzony, nie używaj go i obchodź się z nim ze szczególną ostrożnością.


2. ZAKRES DOSTAWY



UWAGA: Zasilacz nie wchodzi w skład zestawu, należy używać ten element z wyjściem 5 V maks. 2 A z gniazda USB.

3. MONTAŻ

Produkt jest dostarczany w stanie gotowym do użycia, nie wymaga dodatkowej instalacji. Naciśnij przełącznik, aby włączyć lub wyłączyć produkt.



Ten produkt może być podłączony wyłącznie do certyfikowanego i odpowiedniego zasilacza USB, który spełnia wymagania odpowiednie normy IEC/EN 61547.

4. KONSERWACJA I UTRZYMANIE

1. Przed czyszczeniem należy odłączyć urządzenie od gniazda USB.
2. Do czyszczenia produktu należy używać wyłącznie miękkiej, antystatycznej i niestrzępiącej się szmatki. Jeśli oprawa jest bardzo zabrudzona, użyj szmatki z niewielką ilością płynu czyszczącego. Nie używaj oprawy przed całkowitym wyschnięciem wszystkich części. Nie używaj rozpuszczalników ani materiałów ściernych!

5. DANE TECHNICZNE

Napięcie robocze: 5 V DC
Typ żarówki: LED
Całkowita moc wyjściowa: 5 W
Stopień ochrony IP: IP20
Klasa ochrony: III

6. UTYLIZACJA STARYCH URZĄDZEŃ I BATERII, AKUMULATORY I ŹRÓDŁA ŚWIATŁA

Odpady sprzętu elektrycznego oraz zużytych baterii i akumulatorów nie mogą być wyrzucane do niesegregowanych odpadów komunalnych, ponieważ mają potencjalnie negatywny wpływ na zdrowie ludzi i środowisko ze względu na obecność substancji niebezpiecznych.

Użytkownik jest prawnie zobowiązany do pozbycia się wyżej wymienionych urządzeń i komponentów oddzielnie od niesortowanych odpadów komunalnych w oficjalnie zatwierdzonym punkcie odbioru (np. centrum recyklingu/materiałów wartościowych) lub u dystrybutorów/producentów, którzy są zobowiązani do ich odbioru. W ten sposób przyczyniasz się do ich ponownego wykorzystania, recyklingu i innych form odzysku. Jeśli stare baterie, akumulatory lub źródła światła można oddzielić od starego urządzenia bez jego zniszczenia, należy je zutylizować oddzielnie. Szczególnie w przypadku baterii litowych, baterii blokowych i ogniw guzikowych należy zakleić zaciski baterii taśmą, aby zmniejszyć ryzyko zwarcia. Znaczenie symboli chemicznych na bateriach i akumulatorach jest następujące: Hg = rtęć, Cd = kadm, Pb = ołów, Li = lit. Znak przekreślonego kosza na śmieci jest obecny z paskami na urządzeniach elektrycznych i bez pasków na bateriach i akumulatorach, aby przypomnieć o prawidłowej segregacji odpadów.

Ostrzeżenie:

Jeżeli zewnętrzny przewód giętki lub sznur oprawy oświetleniowej jest uszkodzony, powinien być wymieniony przez producenta, w autoryzowanym punkcie serwisowym lub u specjalisty, w celu uniknięcia ryzyka.



Gospodarstwa domowe są użytkownikami sprzętu elektrycznego i elektronicznego, a w konsekwencji potencjalnymi wytwórcami niebezpiecznych dla ludzi i środowiska odpadów, z tytułu obecności w sprzęcie niebezpiecznych substancji, mieszanin oraz części składowych. Odpowiednie postępowanie ze zużytym sprzętem, w szczególności recykling, zapobiega negatywnym konsekwencjom dla środowiska naturalnego i ludzkiego zdrowia.

Symbol przekreślonego kosza na śmieci na produkcie lub w jego opakowaniu oznacza, że sprzęt elektryczny, oraz elektryczny, baterii, oraz akumulatorów, nie wolno wyrzucać do zwykłych pojemników na odpady. Obowiązkiem użytkownika jest przekazanie zużytego sprzętu do wyznaczonego punktu zbiórki w celu recyklingu odpadów powstających ze sprzętu elektrycznego i elektronicznego.

Ten produkt jest oznaczony symbolem selektywnego sortowania, oznaczającym odpady elektryczne i elektroniczne (WEEE). Oznacza to, że z tym produktem należy postępować zgodnie z dyrektywą europejską 2012/19 / UE, aby poddać go recyklingowi lub rozebrać, aby zminimalizować jego wpływ na środowisko. Użytkownik ma możliwość przekazania swojego produktu właściwej organizacji zajmującej się recyklingiem lub sprzedawcy detalicznemu, gdy kupuje nowy sprzęt elektryczny lub elektroniczny.

Właścicielem marki i wytwórcą jest Action S.A.

Action S.A. Zamienie, ul. Dawidowska 10, 05-500 Piaseczno; Poland

activejet.com activejet.pl

safety@action.pl

hotline (PL)/infolinia: 0 801 08 11 11



Wyprodukowano w ChRL

USER MANUAL

PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY.


1. IMPORTANT SAFETY REFERENCES

- The product is not a toy. Keep away from children.
- Avoid dirt, and excessive heat while installing and during operation.
- For indoor use only.
- **Class III product** - designed to be supplied from a SELV (Separated or Safety Extra-Low Voltage) power source. 
- Do not modify or redesign the product.
- Do not attach decorative items to this product.
- Do not stare at the operating light source.



- Unplug the USB connector if you know that the product will not be used for a longer period of time.
- The external flexible cable or cord of this product cannot be replaced; if the cord is damaged, the luminaire must be destroyed.
- The light source of this product is not replaceable, when the light source reaches its end of life the whole product shall be replaced.
- Do not operate the product while it is in the packing.
- If the product is damaged, do not use it and handle it with special care.


2. SCOPE OF DELIVERY



CAUTION: The power supply device doesn't include, operate this item with output 5 V max. 2 A USB outlet power supply.

3. MOUNTING

The product is supplied ready for use, it requires no additional installation. Press the switch to turn the product on or off.



This product must only be connected to an certified and suitable USB power supply which meets the requirements of the relevant standards for IEC/EN 61547.

4. CARE AND MAINTENANCE

1. Unplug the product from USB socket before cleaning
2. To clean the product, use only a soft, anti-static and lint-free cloth. If the luminaire is very dirty use a cloth with a little cleaning liquid. Do not use the luminaire before all parts are completely dry. Do not use solvents or abrasives!

5. TECHNICAL DATA

Operating Voltage: 5 V DC
Bulb Type: LED
Total Output: 5 W
IP Rating: IP20
Protection Class: III

6. DISPOSAL OF OLD APPLIANCES AS WELL AS OLD BATTERIES, ACCUMULATORS AND LIGHT SOURCES

In accordance with Directives 2012/19/EU and 2023/1542/EU, waste electrical equipment as well as waste batteries and accumulators may not be disposed of in unsorted municipal waste, as they have a potentially negative impact on human health and the environment due to the presence of hazardous substances.

You are legally obliged to dispose of the above-mentioned devices and components separately from unsorted municipal waste at an officially approved take-back point (e.g. recycling/valuable materials centre) or at distributors/manufacturers who are obliged to take them back. In doing so, you are making an important contribution to their reuse, recycling and other forms of recovery. The return is free of charge for you. If old batteries, accumulators or light sources can be separated from the old device without destroying it, they must be disposed of separately. Especially in the case of lithium batteries, block batteries and button cells, tape off the battery terminals to reduce the risk of short circuits. The meaning of the chemical symbols on batteries and accumulators are as follows: Hg = mercury, Cd = cadmium, Pb = lead, Li = lithium. The sign of the crossed-out dustbin is present with bars on electrical appliances and without bars on batteries and accumulators to remind you to separate your waste properly.

Warning:

If the outer flexible conduit or cord of the luminaire is damaged, it should be replaced by the manufacturer, at an authorized service center or by a specialist in order to avoid any risk.



Households are users of electrical and electronic equipment and, as a consequence, potential generators of waste hazardous to humans and the environment, due to the presence of hazardous substances, mixtures and components in the equipment. Appropriate treatment of waste equipment, in particular recycling, prevents negative consequences for the environment and human health.

The symbol with the crossed-out wheeled bin on the product or its packaging indicates that electronic and electrical equipment, batteries, and accumulators must not be disposed of in the normal waste containers. It is the user's responsibility to take the used equipment to a designated collection point for the recycling of waste electrical and electronic equipment.

This product is marked with the selective sorting symbol for waste (WEEE). This means that this product must be handled in accordance with European Directive 2012/19 / EU to recycle it or dismantle it to minimise the its impact on the environment. The user has the option of handing in his product to the appropriate recycling organisation or to a retailer when purchasing new equipment electrical or electronic equipment.

The owner of the brand and the manufacturer is Action S.A.

ACTION joint-stock company, Zamienie, 10 Dawidowska St., 05-500 Piaseczno, Poland

activejet.com activejet.pl

safety@action.pl

hotline (PL)/infolinia: 0 801 08 11 11



Made in ChRL